Simultaneous Test-Set III for organic vapors

Order No. 81 01 770

Application Range

Standard Measuring Range and Color Change:

Dräger-Tubes in Simultaneous Test-Set III	1. Scale Mark	2. Scale Mark
1. Ketones	Acetone	
pale yellow → dark yellow	1.000 ppm	5.000 ppm
2. Aromatics	Toluene	
white → brown	100 ppm	500 ppm
3. Alcohols	Methanol	
yellow → mint green	200 ppm	1.000 ppm
4. Aliphatics	n-Hexane	
white → brown	50 ppm	100 ppm
5. Chlorinated hydrocarbons	Perchloroethylene	
yellow white → grey blue	50 ppm	100 ppm
Number of Strokes n:	10	
Time for Measurement:	approx. 40 s	





Ambient Operating Conditions

10 to 30 °C Temperature: Absolute Humidity: 5 to 15 mg H₂O / L

The ranges given for temperature and humidity apply to calibrations with the original substances. Semi-quantitative measurements are also possible outside this range.

Attention

The Simultaneous Test-Set was developed for the semi-quantitative measurement of organic vapors. It is used to estimate and limit risks by obtaining information about health risks or possible intoxication hazards in the area of a fire.

The Simultaneous Test-Set cannot be used to determine the risk of explosion. A negative result with the Simultaneous Test-Set does not exclude the presence of other hazardous gases.